



EN - english

Instructions for installation and operation

Data Display

DD109



Dear customer,

Thank you very much for deciding in favour of the data display DD109. Please read this installation and operation manual carefully before mounting and initiating the device and follow our advice. A riskless operation and a correct functioning of the data display are only guaranteed in case of careful observation of the described instructions and notes.

Headquarter :

Deutschland / Germany

BEKO TECHNOLOGIES GMBH
Im Taubental 7
D-41468 Neuss
Tel.: +49 (0)2131 988 0
beko@beko.de

中华人民共和国 / China

BEKO TECHNOLOGIES (Shanghai) Co.
Ltd.
Rm.606 Tomson Commercial Building
710 Dongfang Rd.
Pudong Shanghai China
P.C. 200122
Tel. +86 21 508 158 85
beko@beko.cn

France

BEKO TECHNOLOGIES S.a.r.l.
Zone Industrielle
1 Rue des Frères Remy
F- 57200 Sarreguemines
Tel. +33 387 283 800
beko@wanadoo.fr

India

BEKO COMPRESSED AIR
TECHNOLOGIES Pvt. Ltd.
Plot No.43/1, CIEEP, Gandhi Nagar,
Balanagar, Hyderabad - 500 037, INDIA
Tel +91 40 23080275
eric.purushotham@bekoindia.com

Italia / Italy

BEKO TECHNOLOGIES S.r.l
Via America 14
I - 10071 Borgaro Torinese (TO)
Tel. +39 0114 500 576
info.it@beko.de

日本 / Japan

BEKO TECHNOLOGIES K.K
KEIHIN THINK 8 Floor
1-1 Minamiatarida-machi
Kawasaki-ku, Kawasaki-shi
JP-210-0855
Tel. +81 44 328 76 01
info@beko-technologies.co.jp

Benelux

BEKO TECHNOLOGIES B.V.
Vaartveld 25
NL - 4704 SE Roosendaal
Tel. +31 165 320 300
info@beko.nl

Polska / Poland

BEKO TECHNOLOGIES Sp. z o.o.
ul. Chłapowskiego 47
PL-02-787 Warszawa
Tel +48 (0)22 855 30 95
info.pl@beko.de

Scandinavia

BEKO TECHNOLOGIES AS
P.O.Box 12 N-1393 Vollen
Leangbukta 31
N-1392 VETTRE
Tel +47 31 29 10 50
kjell@beko-technologies.no

España / Spain

BEKO Tecnológica España S.L.
Polígono Industrial "Armenteres"
C./Primer de Maig, no.6
E-08980 Sant Feliu de Llobregat
Tel. +34 93 632 76 68
info.es@beko.de

South East Asia

BEKO TECHNOLOGIES S.E.Asia
(Thailand) Ltd.
75/323 Romkiao Road
Sansab, Minburi
Bangkok 10510
Thailand
Tel. +66 (0) 2-918-2477
BEKO-info@beko-seasia.com

臺灣 / Taiwan

BEKO TECHNOLOGIES Co.,Ltd
16F.-5, No.79, Sec. 1,
Sintai 5th Rd., Sijhih City,
Taipei County 221,
Taiwan (R.O.C.)
Tel. +886 2 8698 3998
info@beko.com.tw

Česká Republica / Czech Republic

BEKO TECHNOLOGIES s.r.o.
Mlýnská 1392
CZ - 562 01 Usti nad Orlici
Tel. +420 465 52 12 51
info.cz@beko.de

United Kingdom

BEKO TECHNOLOGIES LTD.
2 West Court
Buntsford Park Road
Bromsgrove
GB-Worcestershire B60 3DX
Tel. +44 1527 575 778
beko@beko-uk.com

USA

BEKO TECHNOLOGIES CORP.
900 Great SW Parkway
US - Atlanta, GA 30336
Tel. +1 (404) 924-6900
beko@bekousa.com

1	Safety instructions	4
2	Field of application	6
3	Functions of the data display	6
4	Data display with sensors	6
5	Technical data	7
6	Dimensions	8
7	Mounting	9
8	Plug reverse side	10
9	Connecting diagram reverse side	10
10	Connecting diagrams	10
10.1	Power supply	10
10.2	Alarm connection	11
11	Analogue current signal	11
11.1	Analogue current signal flow sensor	11
11.2	Analogue current signal DPsensor	11
12	Galvanic isolated pulse output	12
12.1	Connecting diagram pulse output flow sensor	12
13	Connection pulse: active high	12
13.1	Connection pulse: active low	12
14	Operation	13
14.1	Description of the display icons	13
14.1.1	Description of the status icons	13
14.2	Operation of the main keys	14
14.2.1	Concept for key operation	14
14.3	Typical menu display layout	14
14.3.1	Selection fields	15
14.3.2	Figure settings	15
14.4	Information after switching on the instrument	15
14.5	Main menu points	16
14.5.1	Logger operation	16
14.5.2	Alarm settings	17
14.5.3	Sensor settings	17
14.5.4	System status and settings	17
15	Scope of delivery	17
16	Conformity declaration	18

1 Safety instructions



Please check whether this manual corresponds with the instruments type.

Please observe all notes indicated in this instruction manual. It contains essential information which have to be observed during installation, operation and maintenance. Therefore this instruction manual has to be read categorically by the technician as well as by the responsible user / qualified personnel before installation, initiation and maintenance.

This instruction manual has to be available at the operation site of data display at any time.

Regional respectively national regulations have to be observed in addition to this instruction manual, if necessary.

In case of any obscurities or questions with regard to this manual or to the instrument please contact BEKO TECHNOLOGIES.



Warning!

Supply voltage!

Contact with supply voltage carrying non-insulated parts may cause an electric shock with injury and death.

Measures :

- Observe all applicable regulations for electrical installations (e. g. VDE 0100)!
- **Carry out maintenance work only in deenergized state!**
- All electric works are only allowed to be carried out by authorized qualified personnel.



Warning !

Inadmissible operating parameters !

Undercutting or exceeding of limit values may cause danger to persons and material and may lead to functional and operational disturbances.

Measures :

- Make sure that the data display is only operated within the admissible limit values indicated on the type label.
- Careful observation of the performance data of the data display in connection with the application.
- Do not exceed the admissible storage and transportation temperature.

Further safety instructions:

- Also the applicable national regulations and safety instructions have to be observed during installation and operation.
- The data display is not allowed to be used in explosive areas.

Additional remarks:

- Do not overheat the instrument!



Attention !

Malfunctions at the data display

Faulty installation and insufficient maintenance may lead to malfunctions of the data display which may affect the measuring results and which may lead to misinterpretations.

Field of application


2 Field of application

- The data display is a stationary display instrument with data logger e. g. for corresponding consumption and dew point sensors (please see "Technical data")
- The data display is used e. g. in the following applications
 - Flow station
 - Dew point set
- For functioning, the data display requires an operating voltage (see Technical data).
- The data display is not suitable for an application in explosive areas


3 Functions of the data display

- Graphics display for an easy user interface
- Flexible voltage supply: 100... 240 VAC/ 50... 60Hz
- 2 inputs for BEKO consumption and dew point sensors
- 4... 20 mA – output for further processing
- 2 relay outputs for alarm
- USB interface
- Housing mountable at the wall or in the panel
- Data logging function for 1,000,000 values

4 Data display with sensors



5 Technical data


	
Dimensions wall housing	Dimensions: 4.65" x 4.53" x 3.66"
Dimensions panel mounting	Dimensions: 3.62" x 3.62"
Housing material	ABS synthetic material
Protection type housing	IP 65
Operating temperature	0... 122°F
Transportation temperature	-4... 158 °F
Sensor inputs	2 inputs for dew point and consumption sensors (optional 2 analogue inputs)
Interface	USB
Keypad	4 keys
Power supply	100 240 VAC / 50-60 Hz / 10 VA
Display	Graphics display, 160 x 100 pixels
Settings	The data display is supplied with standard settings
Alarm output	2 relays, 230 VAC, 3 A, potential-free, change-over contact
Analogue output	Connection of the 4... 20 mA signals of the dew point and consumption sensors (maximum burden < 500 Ohm)
Data logger	<ul style="list-style-type: none"> ▪ up to 1,000,000 values ▪ start time programmable and manually adjustable ▪ logging interval, Min. 1 Sec., Max. 59 Min. 59 Sec. ▪ average value storage <p>Factory settings: Logging interval 10 Sek. Wrap around mode The data logging starts as soon as the instrument is put into operation</p>
Software	The BEKO software SW 109 is available as an option. With this software all settings can be done at DD109 and the logger data can be read-out.

Dimensions

6 Dimensions

	<p>Dimensions wall housing</p> <p>118,0 mm = 4,65" 92,0 mm = 3,62" 115,0 mm = 4,53" 107,5 mm = 4,23" 133,0 mm = 5,24" 25,0 mm = 0,98" 20,0 mm = 0,79"</p>
	<p>Dimensions for panel mounting</p> <p>118,0 mm = 4,65" 115,0 mm = 4,53" 13,5 mm = 0,53" 98,5 mm = 3,88" 70,0 mm = 2,76" 91,7 mm = 3,61" 8,0 mm = 0,31" 92,0 mm = 3,62"</p>

7 Mounting



Mounting wall housing:

The cables for sensors and for the power supply are already wired at DD10:


- Do not connect mains cable to the power line
- Release the 4 screws at the front housing
- Remove plug from the reverse side of the front housing
- Drill holes into the wall according to the given grid dimension (please see drawing)
- Mount wall housing (anchor and screws included in the scope of delivery)
- Attach again plug for the power supply and for the sensors
- Insert the front housing into the wall housing and tighten the 4 screws

At DD109 the cables for sensors and for the power supply are not wired:

- Release the 4 screws at the front housing
- Drill holes into the wall according to the given grid dimension (please see drawing)
- Mount wall housing (anchor and screws included in the scope of delivery)
- Carry out wiring of the power supply and the sensor(s) according to the below instructions
- Insert the front housing into the wall housing and tighten the 4 screws
- Tighten the clamp screwings of the cables

98,8 mm = 3,89"

84,0 mm = 3,31"



Panel mounting

- Cut-out
3,62" (+0,03" -0,0") x 3,62" (+0,03" -0,0")
Maximum sheet thickness 0,31" (see above drawing)
- Insert front housing for panel mounting into the prepared cut-out
- Insert the fixing clips and fix the housing by twisting the thread rods
- Carry out wiring of the power supply and the sensor(s) according to the below instructions

Plug reverse side

8 Plug reverse side


Supply:

AWG12 – AWG24, cable cross-sections: 0.2 ... 2.5 mm²

Signals:

AWG16 ... AWG28, cable cross-sections: 0.14 ... 1.5 mm²

9 Connecting diagram reverse side




Important information:

Please make sure that the configuration you ordered has been matched with the sensors.

10 Connecting diagrams

10.1 Power supply



10.2 Alarm connection

<p style="text-align: center;">Alarm 1 Alarm 2</p>	<p>NC and COM are closed in case of:</p> <ul style="list-style-type: none"> - alarm - power failure - sensor break
---	---

11 Analogue current signal

The flow sensor and the DP sensor offer the possibility to provide the measured values as analogue current signal 4...20 mA for further process treatment . The connection schemes have already been set for this.

11.1 Analogue current signal flow sensor

<p style="text-align: center;">G</p>	<p>Terminal G "Flow sensor"</p> <p>The flow sensor is connected to the clamps at terminal G according to the scheme indicated at the left. The analogue signal (4...20mA) is at clamp 1 and 3 and can be tapped if required (maximum burden < 500 Ohm)</p>
--------------------------------------	---

11.2 Analogue current signal DP sensor

<p style="text-align: center;">I</p>	<p>Terminal I „DP sensor“</p> <p>The DP sensor is connected to the clamps at terminal I according to the scheme indicated at the left. The analogue signal (4...20mA) is at clamp 1 and 2 and can be tapped if required (maximum burden < 500 Ohm). If the analogue signal is not used a wire jumper has to be inserted here obligatorily (factory-provided)</p>
--------------------------------------	---


Galvanic isolated pulse output

12 Galvanic isolated pulse output


A galvanic isolated pulse output is available for the flow sensor. It deals with a semi-conductor relay which is galvanic isolated from the supply voltage by means of optoelectronic couplers.

Maximum switching capacity : U_{max} : 32V, I_{max} : 20 mA


12.1 Connecting diagram pulse output flow sensor



13 Connection pulse: active high




13.1 Connection pulse: active low










14 Operation

The measured values will be indicated page by page. Depending on the sensor and the settings one or several values can be indicated on one display page. These settings can be changed via the optional software or - on request - by BEKO TECHNOLOGIES.

14.1 Description of the display icons

	<p>Status display</p> <p>Indication of measured value: Only one page of measured values will be shown at a time. The use can utilize the „arrow up“ or „arrow down“ keys in order to scroll through all available pages.</p> <p>Page view indication: Shows the current number of pages of measured values as well as the total number of pages.</p>
---	--


14.1.1 Description of the status icons




	<p>These icons show the system status.</p> <p>Explanation of the single icons:</p>
	<p>USB connection icon: The data display is connected to a PC via USB</p>
	<p>Alarm status icon: Alarm 1 (pre-alarm) Alarm 1 is exceeded</p>
	<p>Alarm status icon: Alarm 1 (pre-alarm) Alarm 1 is undercut</p>
	<p>Alarm status icon: Alarm 2 (main alarm) Alarm 2 is exceeded</p>
	<p>Alarm status icon: Alarm 2 (main alarm) Alarm 2 is undercut</p>
	<p>Logger module icon: WAIT: Time and start conditions are set, waits for start logging LOG: Logger module is recording data STOP: Logging stopped DEL: Logger deletes protocol data ERR: Error occurred during data logging LOG 100%: Free memory of logger module in percent CYCLE: Logger memory works in circular mode</p>

Operation


14.2 Operation of the main keys

14.2.1 Concept for key operation




	<ul style="list-style-type: none"> • use these keys to browse and select different items in the menu and scroll through different pages of measurement values • use these keys to alter or adjust the setting option or numbering
 Back	<ul style="list-style-type: none"> • use this key to exit the current menu level • use it to leave all setting state without saving the changes
 Enter	<ul style="list-style-type: none"> • use this key to enter the submenu or next menu level of the currently selected menu item • use it to confirm the setting changes


14.3 Typical menu display layout

	<ul style="list-style-type: none"> • The currently selected menu item will be shown in negative colour • If there is a ">" sign at the right edge it means we can exit the current menu or go to the next higher level • If there is a "<" sign at the left edge it means we can go into the submenu of the currently selected menu • Selectable menu item. It shows 4 items at the same time. If the total items in the current menu are more than 4 items the menu items can be scrolled through • Indication at the bottom: Shows how many items exist in the currently selected menu and it shows the current menu item
---	--



14.3.1 Selection fields

	<ul style="list-style-type: none"> • Options for selection of the parameters <ul style="list-style-type: none"> ○ - Selection field for deselected point ● - Selection field for selected point • Selection of the selection field via the "arrow up" and "arrow down" keys • By means of the "Enter" key the selected option can be activated • Leaving the menu point: <ul style="list-style-type: none"> Use the "Back" key to get back to the last menu level without activating the selected option
---	---

14.3.2 Figure settings

	<p>Example figure settings: Time and date setting in submenu "system status and setting"</p> <ol style="list-style-type: none"> 1. Time setting via "arrow up" and "arrow down" keys 2. Change from HOUR to MINUTE to SECOND with the "Enter" key 3. Upon entry of the SECONDS the setting is terminated and stored by the "Enter" key. By using the "Back" key the menu point "Time and date setting" can be left without storing the settings.
--	---

14.4 Information after switching on the instrument

	<p>System information are indicated for approx. 5 seconds after switching on the data display:</p> <p>The system information is helpful for service questions in order to determine e. g. the version number and the firmware version.</p> <p>The system information can be called up at any time in the menu point "system info".</p>
	<p>If the sensors are connected in accordance with the configuration the data display will automatically recognize them and start to indicated real time measured values which are received from the sensors. It is possible that measured values are indicated on more than one page. The "arrow up" or the "arrow down" key can be used in order to indicate a further page.</p>

Operation

14.5 Main menu points

The data display is supplied with standard settings.

Main menu points in the data display:

- Logger operation
- Set Alarm 1
- Set Alarm 2
- Sensor setting
- Communication settings (Option BUS systems)
- System status and setting


14.5.1 Logger operation

Set logging rate	Set storage interval and average value determination The storage interval defines the time interval in which the data should be recorded. One value is recorded of each activated channel. The option average value determination can be used in order to determine the average value, i. e. the data display measures every second and if the storage interval is 10 seconds the average from the last 10 values will be made up and stored as measured value.
Key start logging	Start/stop, recording Starts or stops the data recording. A new file is created in the memory as soon as a new recording is started.
Set time start condition	Set time, start conditions The data display can be programmed so that it starts measurement at a certain point of time.
Memory status	Show logger memory status Shows the status and the size of the available memory
View protocol	Single protocols (files) or the whole memory can be indicated and if necessary deleted. The data display shows the available protocols with date, the number of channels, the number of recorded data per channel and the min/max/average value.
Delete protocol	Deletes the selected protocol.
Format logger	Deletes the internal memory.

14.5.2 Alarm settings

It is possible to set 2 individual alarm thresholds:

1. "Set Alarm 1 threshold"
2. "Set Alarm 2 threshold"

	<p>In this example the sensor is connected to terminal I. „Type: High" means: The alarm is triggered if the value is higher than the threshold. If the alarm is exceeded or dropped below the background becomes red resp. starts blinking.</p> <p>The factory setting of the hysteresis is 35°F td.</p> <p>Please observe that these adjustments cannot be changed directly in the Data Display. Please turn to BEKO TECHNOLOGIES GMBH</p>
---	---

14.5.3 Sensor settings

Sensor settings for our consumption or dew point sensors are stored within the sensor itself. The Data Display can be used in order to change those settings. For this purpose, select in the menu the function "Sensor settings". On the next screen the available inputs are shown: e. g.

- Terminal I: Dew point
- Terminal G: Consumption

Select the desired entry mask in order to carry out the sensor settings.

If a sensor is connected to a switched on Data Display, the configuration of the Data Display will be transferred to the sensor without any prior query. (e.g. analogue output, diameter for consumption probes ...)

On delivery of a unit Data Display/sensor the adjustments are matched. Please check the coordination if you connect sensors with deviant adjustments to the Data Display.

14.5.4 System status and settings

Setup time/date	Set the integrated clock.
Show system status	This screen contains important information for service enquiries.
Change LCD contrast	Contrast of the display can be changed.
System reset	In case other sensors are connected it is recommended to use this function in order to update the system settings.

15 Scope of delivery

- Data Display in wall housing according to your order
- Fastening clips for panel mounting
- Instruction manual

16 Conformity declaration

BEKO TECHNOLOGIES GMBH
41468 Neuss, GERMANY
Tel: +49 2131 955-0
www.beko.de



EG-Konformitätserklärung

Wir erklären hiermit, dass die nachfolgend bezeichneten Produkte in der von uns gelieferten Ausführung den Anforderungen der einschlägigen Normen entsprechen:

Produktbezeichnung:	DD109
Spannungsversorgung:	100 – 240 VAC / 50-60 Hz / 10 VA
Produktbeschreibung und Funktion:	Datendisplay zum Erfassen und Anzeigen von Messwerten

Niederspannungs-Richtlinie 2006/95/EG Angewandte harmonisierte Normen:	EN 61010-1:2001 EN 61010-31:2002 + A1:2008
Anbringungsjahr der CE-Kennzeichnung:	09

EMV-Richtlinie 2004/108/EG Angewandte Normen:	Störaussendung: EN 61326:1997 + A1:1998 + A2:2001 + A3:2003 Störfestigkeit: EN 61326:1997 + A1:1998 + A2:2001 + A3:2003
---	--

Die Produkte sind mit dem abgebildeten Zeichen gekennzeichnet:



Diese Erklärung bezieht sich nur auf die Produkte in dem Zustand, in dem sie in Verkehr gebracht wurden; nicht vom Hersteller angebrachte Teile und/oder nachträglich vorgenommene Eingriffe bleiben unberücksichtigt.

Neuss, 30.03.2009

BEKO TECHNOLOGIES GMBH


i.V. Christian Riedel
Leiter Qualitätsmanagement

BEKO TECHNOLOGIES GMBH
41468 Neuss, GERMANY
Phone: +49 2131 988-0
www.beko.de



EC Declaration of Conformity

We herewith declare that the product indicated in the following in the version supplied by us corresponds with the requirements of the relevant standards:

Product designation:	DD109
Voltage supply:	100 – 240 VAC / 50-60 Hz / 10 VA
Product description and function:	Data display for recording and indication of measured data

Low voltage directive 2006/95/EG

Applied harmonized standards:	EN 61010-1:2001 EN 61010-31:2002 + A1:2008
Year of fitting with CE mark:	09

EMV directive 2004/108/EG

Applied standards:	Emitted interference: EN 61326:1997 + A1:1998 + A2:2001 + A3:2003
	Interference resistance: EN 61326:1997 + A1:1998 + A2:2001 + A3:2003

The products are labeled with the indicated mark:



This declaration only refers to the products in the state in which they are put into circulation, parts which are not attached by the manufacturer and/or subsequently taken interventions stay unconsidered.

Neuss, 30.03.2009

BEKO TECHNOLOGIES GMBH

i.V. Christian Riedel
Head of Quality Management

A		L	
Active high	12	Logger module icon	13
Active low.....	12	Logger operation.....	16
Alarm 1 (pre-alarm)	13	M	
Alarm 1 exceeded.....	13	Main functions of the data display	6
Alarm 1 undercut	13	Main menu points	16
Alarm 2 (main alarm).....	13	Maximum switching capacity	12
Alarm connection.....	11	Mounting	9
Alarm exceeded or dropped below.....	17	Mounting wall housing	9
Alarm settings.....	17	O	
Analogue current signal 4...20 mA	11	Operating voltage	6
Applications	6	Operation of the main keys.....	14
B		P	
Back key	14	Panel mounting	9
C		Power supply	10
Concept for key operation	14	Process treatment.....	11
Conformity declaration.....	18	Pulse counter	12
Connecting diagram reverse side.....	10	Pulse output flow sensor.....	12
Connection pulse: active high	12	Q	
Connection pulse: active low	12	Qualified personnel.....	4
Contrast of the display	17	R	
D		Red background	17
Data display with sensors.....	6	S	
Dimensions	8	Safety instructions	5
Dimensions for panel mounting	8	Safety instructions	4
Dimensions wall housing	8	Scope of delivery	17
Display icons	13	Selection field parameters	15
E		Sensor settings	17
Enter key.....	14	Status icons	13
Explosive area	6	System status and settings.....	17
F		T	
Faulty installation.....	5	Technical data	7
Field of application.....	6	Typical menu display layout.....	14
Figure settings	15	U	
G		USB interface.....	6
Galvanically separated pulse output	12	W	
H		Warning inadmissible operating parameters	4
Hysteresis	17	Warning supply voltage	4
I			
Information after switching on the instrument.....	15		

Technical changes and errors excepted.
DD109_manual_en_2009-03